




Compilation Data

Levelled.....1957

Boundaries.....Jul 1978

(b) Sep 1977

1:2500 scale

1:1250 scale (photographically reduced)

(a) Surveyed.

(b) Reconstructed from former County Series plans and revised.

(c) Revised.

Surveys of changes since the publication of this plan may be available. Enquiries should be addressed to the Director General or to the local Ordnance Survey office.

HEIGHTS are given in METRES above the Newlyn Datum.

Bench mark lines, which may contain lower levelling information and particulars of bench marks to which no values have been shown, are obtainable from the Director General, Ordnance Survey.

CONVERSION SCALES

HECTARES-ACRES

1 hectare = 2.471 acres

1 acre = 0.4047 hectares

1 metre = 3.2808 feet

1 foot = 0.3048 metres

ABBREVIATIONS

|      |                |          |                         |        |                     |
|------|----------------|----------|-------------------------|--------|---------------------|
| B.H. | Bear House     | L.B.     | Lifeboat Station        | R.H.   | Road House          |
| B.P. | Boundary Post  | L.C.     | Level Crossing          | rp     | Revision Point      |
| B.S. | Boundary Stone | L.G.     | Landing Glass           | S.     | Stone               |
| C.H. | Club House     | L.H.     | Lighthouse              | S.B.   | Signal Box          |
| Ch.  | Chimney        | L.T.     | Lighting Tower          | S.D.   | Signal Dish         |
| Ch.  | Chimney        | M.       | Mill                    | S.L.   | Signal Light        |
| Ch.  | Chimney        | M.H.W.   | Mean High Water         | S.P.   | Signal Post         |
| Ch.  | Chimney        | M.H.W.S. | Mean High Water Springs | Sp.    | Spring              |
| Ch.  | Chimney        | M.L.W.   | Mean Low Water          | S.S.   | Signal Station      |
| Ch.  | Chimney        | M.L.W.S. | Mean Low Water Springs  | T.C.B. | Telephone Call Box  |
| Ch.  | Chimney        | M.L.W.S. | Mean Low Water Springs  | T.C.P. | Telephone Call Post |
| Ch.  | Chimney        | M.L.W.S. | Mean Low Water Springs  | T.     | Tank or Trunk       |
| Ch.  | Chimney        | M.L.W.S. | Mean Low Water Springs  | Tr.    | Trough              |
| Ch.  | Chimney        | M.L.W.S. | Mean Low Water Springs  | W.     | Wall                |

SYMBOLS

Non-coniferous trees

Coniferous trees

Surveyed trees

Orchard trees

Copples, oaks

Scrub

Roofed building

Glasshouse

Site of antiquity

Culvert

Direction of water flow

Pylon

Electricity Transmission Line

Triangulation station

Traverse station (permanent)

Traverse station

Bench mark

BOUNDARIES

ENGLAND & WALES

County

District

London Borough

Civil Parish (England)

Community (Wales)

Electoral Division

Ward

Constituency (Co or Boro)

SCOTLAND

Region or Islands Area

District

Electoral Division

Ward

Constituency (Co or Boro)

COINCIDENT BOUNDARIES are shown by the first appropriate symbol above, e.g. Boro Const & E.D. Bdy

For Ordnance Survey purposes County Boundary is deemed to be the limit of the parish structure whether or not a parish area adjoins.

AREAS

Area measurement is to plan edge only.

The number and area, in hectares (ha) and acres, is shown within each parcel of land.

EXAMPLE:

4267..... parcel number

1.809ha..... area in hectares

4.47..... area in acres

When identifying a parcel it is important to specify the number of the plan on which it falls.

Enclosures or features joined for measurement of area.....

Limit of area within which individual parcels are not shown.....

To convert hectares to acres multiply by 2.471 05

To convert acres to hectares multiply by 0.4046 85

NATIONAL GRID REFERENCE

The grid lines form part of the National Grid and are at 100 metre intervals. To give a unique reference defining the position of a point to within 10 metres proceed as follows—

EXAMPLE from sheet TO 0529

1. Take the two letters preceding the sheet number..... TO

2. Take the west edge of the grid square in which the point lies and read the figures opposite this line on the north or south margin..... 058

3. Estimate tenths of metres from the grid line to the point (distance..... 8

The resulting four figure number is the Easting..... 0588

4. Take the south edge of the grid square in which the point lies and read the figures opposite this line on the east or west margin..... 281