




MADE AND PUBLISHED BY THE DIRECTOR GENERAL OF THE ORDNANCE SURVEY, SOUTHAMPTON.

1:50,000 scale
Levelled.....1967
Boundaries.....Dec 1976

Abbreviations:
B.H. Bear House
B.M. Bench Mark
B.P. Boundary Post
B.S. Boundary Stone
C.H. Club House
Ch. Chimney
Cn. Copse
D.F. Drinking Fountain
E.P. Electricity Pylon or Pole
E.T.L. Electricity Transmission Line
F.A.P. Fire Alarm
F.B. Filter Bed or Foot Bridge
F.H. Fundamental Bench Mark
F.P. Flagstaff
F.S. Fire Station
G.P. Guide Post
G.V.C. Gas Valve Compound
H. Hydrant or Hydraulic
L.B. Lateral Box
L.B.S. Lifeboat Station
L.C. Level Crossing
L.G. Loading Gauge
L.H. Lighthouse
L.T. Lighting Tower
M.H.W. Mean High Water
M.L.W. Mean Low Water
M.L.W.S. Mean Low Water Springs
N.P. Normal Tidal Limit
N.T.L. Normal Tidal Limit
P. Pillar, Pole or Post
P.C. Public Convenience
P.C.B. Police Call Box
P.H. Public House
P.O. Post Office
P.P. Pump
P.T.F. Police Telephone Pillar
R.H. Road House
R.P. Revision Point
S. Stone
S.B. Signal Box
S.L. Signal Light
S.D. Signal
S.P. Spring
S.S. Signal Station
T.C.B. Telephone Call Box
T.C.P. Telephone Call Post
T.K. Tank or Truck
T.T. Trough
T. Traversing Station
W.B. Well
W.B.P. Wind Pump
W.P. Water Point
W.T. Water Tap
R.H. Road House
R.P. Revision Point
S. Stone
S.B. Signal Box
S.L. Signal Light
S.D. Signal
S.P. Spring
S.S. Signal Station
T.C.B. Telephone Call Box
T.C.P. Telephone Call Post
T.K. Tank or Truck
T.T. Trough
T. Traversing Station
W.B. Well
W.B.P. Wind Pump
W.P. Water Point
W.T. Water Tap

CONVERSION SCALES
HECTARES-ACRES
METRES-FOOT
1 metre = 3.2808 feet
1 foot = 0.3048 metres

SYMBOLS
Non-coniferous trees
Coniferous trees
Surveyed trees
Orchard trees
Copse, etc.
Scrub
Heath
Rough ground
Marsh
Rocks
Rivers
Roads

BOUNDARIES
Coincident boundaries are shown by the first appropriate symbol above, e.g. Boro Const & E.D. Bay
Per Ordnance Survey purpose County Boundary is deemed to be the limit of the parish structure whether or not a parish area exists.

ENGLAND & WALES
County
Civil Parish (England)
Community (Wales)
Electoral Division
Ward
Constituency (Co or Boro)

SCOTLAND
Region or Islands Area
District
Electoral Division
Ward
Constituency (Co or Burgh)

AREAS
Area measurement is to plan edge only.
The number and area, in hectares (ha) and acres, is shown within each parcel of land.
EXAMPLE: 4267 parcel number
1-809ha area in hectares
1-47 area in acres
When identifying a parcel it is important to specify the number of the plan on which it falls.
Enclosures or features joined for measurement of area are shown by a line with a cross-tick.
Limit of area within which individual parcels are not shown.
To convert hectares to acres multiply by 2.47105.
To convert acres to hectares multiply by 0.40469.

NATIONAL GRID REFERENCE
The grid lines form part of the National Grid and are at 100 metre intervals. To give a unique reference defining the position of a point to within 10 metres proceed as follows:
EXAMPLE from sheet TQ 0529
1. Take the two letters preceding the sheet number..... TQ
2. Take the west edge of the grid square in which the point lies and read the figures opposite this line on the north or south margin..... 272
3. Take the south edge of the grid square in which the point lies and read the figures opposite this line on the east or west margin..... 058
4. The full four figure number is the Easting..... 2721
5. The full four figure number is the Northing..... 0588
6. The full four figure number is given by writing first the letters, followed by the Easting and then by the Northing..... TQ 0588216
For further information see 'An Introduction to the Projection for Ordnance Survey Maps and the National Reference System.'

26,66