



Made and published by the Director General of the Ordnance Survey, Southampton.

CONVERSION SCALES

Metres 0 100 200 300 400 500 600 700 800 900 1000 1100 1200

Feet 0 300 600 900 1200 1500 1800 2100 2400 2700 3000 3300 3600

1 metre = 3.2808 feet

1 foot = 0.3048 metre

COMPILATION DATA

Levelled.....1952

Boundaries.....Oct 1978

1:2500 scale

(a) Surveyed

(b) Reconstituted from former County Series plans and revised.

(c) Revised.

Survey of changes since the publication of this plan may be available. Enquiries should be addressed to the Director General or to the local Ordnance Survey office.

HEIGHTS are given in METRES above the Newlyn Datum.

Bench mark levels have been shown, are obtainable from the Director General, Ordnance Survey.

The alignment of tunnels where shown is approximate.

ABBREVIATIONS

B.H.	Bench House	L.C.	Level Crossing	R.H.	Road House
B.P.	Boundary Post	L.G.	Loading Gasp	rp	Revision Point
B.S.	Boundary Stone	L.H.	Lighthouse	S	Steeple
C.	Crest	L.T.	Lighting Tower	S.B.	Signal Box
C.H.	Club House	M.	Mere	S.B.R.	Signal Bridge
Chy	Chimney	M.H.W.	Mean High Water	S.D.	Sundial
Cn	Cannon	M.H.W.S.	Mean High Water Springs	S.L.	Signal Light
D.F.	Drinking Fountain	M.L.W.	Mean Low Water	Sl	Sluice
E.P.	Electricity Pole or Post	M.L.W.S.	Mean Low Water Springs	S.P.	Signal Post
E.T.L.	Electricity Transmission Line	M.P.	Mill or Pile or Post	Spr	Spring
F.A.	Fire Alarm	N.T.L.	Normal Tidal Limit	S.S.	Signal Station
F.A.P.	Fire Alarm Pillar	P.	Pillar, Pole or Post	T.C.B.	Telephone Call Box
F.B.	Fiber Bed or Four Bridge	P.S.	Public Sign	T.C.P.	Telephone Call Post
F.B.M.	Fundamental Bench Mark	P.L.	Public Lane	Tk	Tank or Tank
F.S.	Flagstaff	P.L.P.	Public Lane Post	T.S.	Traverse Station
F.St.	Fire Station	P.L.P.P.	Public Lane Post Pillar	Tr	Track
G.P.	Guide Post	P.C.	Public Convenience	Tr.S.	Traverse Station (benchmark)
G.V.C.	Gas Valve Compound	P.C.B.	Public Call Box	Tr.S.	Traverse Station (benchmark)
H.	Hedgerow or Hydraulic	P.O.	Public Office	Tr.S.	Traverse Station (benchmark)
ha.	Hectares	P.O.	Post Office	Tr.S.	Traverse Station (benchmark)
ha.	Hectares	P.P.	Post Office	Tr.S.	Traverse Station (benchmark)
L.B.	Letter Box	P.P.	Post Office	Tr.S.	Traverse Station (benchmark)
		P.P.P.	Police Telephone Pillar		

SYMBOLS

Non-coniferous trees

Coniferous trees

Surveyed trees

Orchard trees

Coppice, over

Scrub

Heath

Bracken, rough grassland

Marsh

Saltings

Reeds

Slopes

Cliff

Cave entrance

Rock

Sloping boundary

Roofed building

Greenhouse

Archway

Change of boundary meaning

See AREAS notes

Site of antiquity

Colvert

Direction of water flow

Electricity Transmission Line

Electricity pylon

Traverse station (benchmark)

AREAS

Area measurement is to plan edge only.

Enclosures or features joined for measurement of area.

The number and area, in hectares (ha) and acres, is shown within each parcel of land.

EXAMPLE: 1.809ha area in hectares

4.47 area in acres

When identifying a parcel it is important to specify the number of the plan on which it falls.

Enclosures or features joined for measurement of area.

Limit of area within which individual parcels are not shown.

To convert hectares to acres multiply by 2.47105

To convert acres to hectares multiply by 0.404686

NATIONAL GRID REFERENCE

The grid lines form part of the National Grid and are at 100 metre intervals. To give a unique reference defining the position of a point within 10 metres proceed as follows:

EXAMPLE: from sheet TQ 0529

1. Take the two letters preceding the sheet number.
2. Take the west edge of the grid square in which the point lies and read the figure opposite this line on the north or south margin.
3. Take the south edge of the grid square in which the point lies and read the figure opposite this line on the east or west margin.
4. The full ten metre reference is given by writing first the letters, followed by the Easting and then by the Northing.

For further information see 'An Introduction to the Projection for Ordnance Survey Maps and the National Reference System'.