

ORDNANCE SURVEY

PLAN SU 2823 & PLAN SU 2923

PARCEL NUMBERS AND ACREAGES
The number and acreage of each parcel of land is shown within the parcel. It is important when identifying a parcel to specify the number(s) of the plan(s) on which it falls.
IN PARCELS DIVIDED BY THE SHEET EDGE, THE ACREAGES ARE SHOWN TO SHEET EDGE ONLY.

Revised December 1965
Levelled 1959

Scale: 1:2500 or 25.344 inches to 1 mile

Revised December 1965
Levelled 1959

The West half of this sheet is Plan SU 2823
The East half of this sheet is Plan SU 2923

PLAN SU 2823 & PLAN SU 2923



Made and published by the Director General of the Ordnance Survey, Chessington, Surrey, 1967.
Reconstituted from former County Series plans and revised 1965.

Conversion Scale Acres-Hectares
Acres 0 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29
Hectares 0 1 2 3 4 5 6 7 8 9 10 11 12

REFERENCE

NATIONAL GRID REFERENCE

The lines on the plan form part of the National Grid and are spaced at 100 metres intervals.
To give a large scale reference defining the position of a point to the nearest 10 metres proceed as follows—
EXAMPLE F in Manor Farm

EASTING	NORTHING
Take west edge of square in which point lies and read the figures opposite this line on NORTH and SOUTH margins	Take south edge of square in which point lies and read the figures opposite this line on EAST and WEST margins
Estimate tens of metres from the grid line	Estimate tens of metres from the grid line
2932	2302

TEN METRE REFERENCE: SU 2932302

For further information see "The Projection for Ordnance Survey Maps and Plans and the National Reference System".
The representation on this plan of a road, track or path is not evidence of the existence of a right of way.
1 square inch on this plan represents 1960 of an acre on the ground.
The alignment of roads where shown is approximate.

Bier House	BH	Letter Box	LB	Revision Point	RP
Bench Mark	BM	Level Crossing	LC	Signal Box, or Post	SB, SP
Boundary Post	BP	Loading Gauge	LG	Signal Bridge	SB
Boundary Stone	BS	Mail Pick-up	MPU	Spring	SPR
Captain, Crane	CN, C	Mile or Mooring Post	MP	Stone	S
Drinking Fountain	DF	Mile Stone	MS	Sundial	SD
Electricity Pillar or Post	EP	Pillar, Pole or Post	P	Tank or Track	T
Electricity Transmission Line	ETL	Police Call Box	PCB	Telephone Call Box	TCB
Fire Alarm Pillar	FAP	Police Telephone Pillar	PTP	Traverse Station	TS
Flagstaff	FS	Post Office	PO	Water Point, or Tap	WP, W, T
Foot Bridge	FB	Public Convenience	PC	Weightbridge	WB
Fundamental Bench Mark	FMB	Public House	PH	Well	W
Guide Post	GP	Pump	P	Wind Pump	WP
Mean High or Low Water	MHW or MLW				

PARCEL NUMBERS AND ACREAGES
The number and acreage of each parcel of land is shown within the parcel. It is important when identifying a parcel to specify the number(s) of the plan(s) on which it falls.

IN PARCELS DIVIDED BY THE SHEET EDGE, THE ACREAGES ARE SHOWN TO SHEET EDGE ONLY.
To convert acres to hectares multiply by 0.40486
To convert hectares to acres multiply by 2.47104

PLAN SU 2823 & PLAN SU 2923

PLAN SU 2823 & PLAN SU 2923