





Produced and published by the Director General of the Ordnance Survey, Southampton.

COMPILED DATA
Levelled 1939
Boundaries Feb 1979

Scale
1:2500 scale * 1:1250 scale (photographically reduced)
(a) Surveyed
(b) Reconstructed from former County Series plans and revised
(c) Revised

HEIGHTS are given in METRES above the Newlyn Datum.
Bench mark lists, which may contain later levelling information and particulars of bench marks to which no values have been shown, are obtainable from the Director General, Ordnance Survey.
The representation on this plan of a road or path is in accordance with the existence of a right of way.
The alignment of tunnels where shown is approximate.



ABBREVIATIONS table listing symbols and their corresponding features like Beer House, Bench Mark, Boundary Post, etc.

SYMBOLS table listing symbols for non-coniferous trees, coniferous trees, surveyed trees, etc.

SYMBOLS table listing symbols for slopes, cave entrance, direction of water flow, etc.

BOUNDARIES table listing symbols for England & Wales, Scotland, and National Grid Reference.

BOUNDARIES table listing symbols for various boundary types like Boro Const. Bdy, E.D. Bdy, etc.

AREAS
The number and area, in hectares (ha) and acres, is shown within each parcel of land.
EXAMPLE: 4267 parcel number
1-807ha area in hectares
4.47 area in acres
When identifying a parcel it is important to specify the number of the plan on which it falls.
Enclosures or forests joined for measurement of area
Limits of area within which individual parcels are not shown
To convert hectares to acres multiply by 2.471 05
To convert acres to hectares multiply by 0.404 69

NATIONAL GRID REFERENCE
The grid lines form parts of the National Grid and are at 100 metre intervals. To give a unique reference defining the position of a point within 10 metres proceed as follows -
EXAMPLE from sheet TQ 0529
1. Take the two letters preceding the sheet number: TQ 058
2. Take the west edge of the grid square in which the point lies and read the figures opposite this line on the north or south margin: 058
Estimate tens of metres from the grid line to the point (distance in): 8
The resulting four figure number is the Easting: 0588
3. Take the south edge of the grid square in which the point lies and read the figures opposite this line on the east or west margin: 291
Estimate tens of metres from the grid line to the point (distance in): 6
The resulting four figure number is the Northing: 2916
4. The full ten metre reference is given by writing first the letters, followed by the Easting, and then by the Northing: TQ 0588 2916
For further information see: An Introduction to the Projection for Ordnance Survey Maps and the National Reference System