



Drawn by Salisbury District Council from unpublished survey information supplied by the Ordnance Survey.

Area measurement is to plan edge only. The number and area, in hectares (ha) and acres, is shown within each parcel of land.

EXAMPLE: 4367 parcel number
1.809ha area in hectares
4.47 area in acres

When identifying a parcel it is important to specify the number of the plan on which it falls. Enclosures or features joined for measurements of area.

Limits of area within which individual parcels are not shown.

To convert hectares to acres multiply by 2.471 05
To convert acres to hectares multiply by 0.404 69

COMPILED DATA

Levelled Boundaries

1:2500 scale
1:2500 scale (photographically reduced)

(a) Surveyed
(b) Reconstituted from former County Series plans and revised
(c) Revised

Surveys of changes since the publication of this plan may be available. Enquiries should be addressed to the Director General or to the local Ordnance Survey office.

HEIGHTS are given in METRES above the Newlyn Datum.

Bench mark lists which may contain later leveling information and particulars of bench marks to which no values have been shown, are obtainable from the Director General, Ordnance Survey.

The representation of the plan of roads, tracks or paths is indicative of the existence of a right of way. The alignment of boundaries where shown is approximate.

ABBREVIATIONS

B.H.	Bear House	L.B. Sta.	Lifeboat Station	P.T.P.	Police Telephone Pillar
B.M.	Bench Mark	L.C.	Level Crossing	R.H.	Road House
B.P.	Boundary Post	L.G.	Loading Gauge	R.P.	Revision Point
B.S.	Boundary Stone	L.H.	Lighthouse	S.	Stone
C.	Crane	L.T.	Lighting Tower	S.B.	Signal Box
C.H.	Club House	L.S.	Lightning Rod	S.B.	Signal Bridge
Ch.	Chimney	M.H.W.	Mean High Water	S.D.	Sundial
Cn.	Capstan	M.H.W.S.	Mean High Water Springs	S.L.	Signal Light
D.F.	Drilling Fountain	M.L.W.	Mean Low Water	S.P.	Signal Post
Dk.	Dock	M.L.W.S.	Mean Low Water Springs	Sl.	Slope
E.P.	Electricity, Pillar or Pole	M.P.	Mile or Mooring Post	S.S.	Signal Station
E.T.L.	Electricity Transmission Line	M.P.U.	Mile Pick-up	S.Sia.	Spring
F.A.	Fire Alarm	M.S.	Mile Stone	T.C.B.	Telephone Call Box
F.B.	Fire Bell or Fire Bell	N.T.	National Trust	T.C.P.	Telephone Call Post
F.F.	Face of Fence	N.T.L.	Normal Tidal Limit	Tk.	Track or Trough
F.H.	Fundamental Bench Mark	N.T.S.	National Trust for Scotland	Tr.	Trough
F.S.	Flagstaff	P.	Pillar, Pole or Post	Tr.	Traverse Station
F.Sta.	Fire Station	P.U.M.	Pillar, Pole or Post	W.	Well
G.P.	Guide Post	P.U.M.	Public Utility Mains	W.B.	Weightbridge
G.V.C.	Gas Valve Compound	P.C.B.	Police Call Box	W.P.	Wind Pump
H.	Hydraulic	P.H.	Public House	W.P.	Water Point
H.	Hydraulic	P.O.	Post Office	W.Pt.	Water Point
H.	Hydraulic	P.	Pump	W.T.	Water Tap
H.	Hydraulic	Pp.	Pump		

SYMBOLS

Non coniferous trees	Slopes	Site of antiquity
Coniferous trees	Cliff	Colliery
Surfaced trees	Cave entrance	Direction of water flow
Coppice cover	Rock	Electricity pylon
Strub	Boulders	Triangulation station
Bracken	Sloping masonry	Traverse station (permanent)
Heath	Roofed building	Bench mark
Rough grassland	Glasshouse	Surface level
Marsh	Archway	Revision point
Reeds	Change of boundary marking	Revision point & bench mark coincident

BOUNDARIES

England & Wales	Scotland	Geographical County
County Boundary	County Boundary	County of the City
County Borough	County of the City	County of the City
County District	County of the City	County of the City
Civil Parish	County of the City	County of the City
Rural Parish	County of the City	County of the City
Parish Consistency & Ward	County of the City	County of the City

NATIONAL GRID REFERENCE

The grid lines form part of the National Grid and are at 100 metre intervals. To give a unique reference defining the position of a point to within 10 metres proceed as follows—

EXAMPLE from sheet TQ 029 058

- Take the two letters preceding the sheet number: TQ 291 058
- Take the west edge of the grid square in which the point lies and read the figures opposite this line on the north or south margin: 291 058
- Take the south edge of the grid square in which the point lies and read the figures opposite this line on the east or west margin: 291 058
- The resulting four-figure number is the Northing: 291 058

The full ten metre reference is given by writing first the letters, followed by the Easting and then by the Northing: TQ 0582916

For further information see 'An Introduction to the Projection for Ordnance Survey Maps and the National Reference System.'

