



Compilation Data
 Levelled 1939
 Boundaries Feb 1979
 (a) Surveyed
 (b) Reconstituted from former County Series plans and revised.
 (c) Revised.

Surveys of changes since the publication of this plan may be available. Enquiries should be addressed to the Director General or to the local Ordnance Survey office.

HEIGHTS are given in METRES above the Newlyn Datum.
 Bench mark lists, which may contain later levelling information and particulars of bench marks to which no values have been shown, are obtainable from the Director General, Ordnance Survey.
 The representation on this plan of a road, track or path is a convenience of the existence of a right of way.
 The alignment of tunnels where shown is approximate.

CONVERSION SCALES

HECTARES-ACRES

METRES-FEET

1 metre = 3.2808 feet
 1 foot = 0.3048 metre

ABBREVIATIONS

B.H.	Bear House	L.B. Sta.	Lifboat Station	R.H.	Road House
B.M.	Bench Mark	L.C.	Level Crossing	rp	Revision Point
B.P.	Boundary Post	L.G.	Loading Gauge	S	Stone
B.S.	Boundary Stone	L.H.	Lighthouse	S.B.	Signal Box
C	Crane	L.T.	Lighthouse Tower	S.B.R.	Signal Bridge
C.H.	Club House	M	Metres	S.D.	Sundial
Chy	Chimney	H.H.W.	Mean High Water	S.L.	Signal Light
Co	Capitan	H.H.W.S.	Mean High Water Springs	Sl	Sluice
D.Fn.	Drinking Fountain	H.L.W.	Mean Low Water	S.P.	Signal Post
E.P.	Electricity Pillar or Pole	H.L.W.S.	Mean Low Water Springs	S.S.	Signal Station
E.T.L.	Electricity Transmission Line	H.W.S.	High Water Springs	S.Si	Signal
F.A.	Fire Alarm	M.P.U.	Mail Pick-up	T.C.B.	Telephone Call Box
F.A.P.	Fire Alarm Pillar	M.S.	Man Sione	T.C.P.	Telephone Call Post
F.B.	Fiber Rod or Foot Bridge	N.T.L.	Normal Tidal Level	Tr	Trough
F.B.M.	Fundamental Bench Mark	P.P.	Pillar, Pole or Post	Trs	Traverse Station
F.S.	Foghorn	P.W.	Public Path	W	Well
F.Sta.	Fire Station	P.C.	Public Convenienc	W.B.	Water Bank
G.P.	Guide Post	P.C.B.	Police Call Box	W.P.	Wind Pump
G.V.C.	Gas Valve Compound	P.H.	Public House	Wk	Works
H	Hydrant or Hydraulic	P.O.	Post Office	W.Pi	Water Point
ha	Hectares	Pp	Pump	W.T.	Water Tap
l.b.	Letter Box	P.T.P.	Police Telephone Pillar		

SYMBOLS

	Non-coniferous trees		Site of antiquity
	Coniferous trees		Culvert
	Surveyed trees		Direction of water flow
	Orchard trees		Pylon
	Coppice, oster		Electricity Transmission Line
	Scrub		Triangulation station
	Heath		Traverse station (permanent)
	Bracken rough grassland		Bench mark
	Marsh		Surface level
	Archway		Revision point
	Change of boundary mering		Revision point & bench mark coincident
	see AREAS notes		

BOUNDARIES

	England & Wales County Boundary		Scotland Region or Islands Area Boundary
	London Borough Community (Wales) Electoral Division Boundary		No boundary
	E.D. Bdy		Electoral Division Boundary
	Boro Const. Bdy		Ward Boundary
	Burgh Const. Bdy		Constituency (Co or Boro) Boundary
	Co Const. Bdy		

Consistent boundaries are shown by the first appropriate symbol above. e.g. Boro Const. & E.D. Bdy.

For Ordnance Survey purposes County Boundary is deemed to be the limit of the parish structure whether or not a parish area adjoins.

AREAS

Area measurement is in plan edge only.
 The number and area, in hectares (ha) and acres, is shown within each parcel of land.

EXAMPLE: 1.807ha area in hectares
 4.427 area in acres

When identifying a parcel it is important to specify the number of the plan on which it falls. Enclosures or features joined for measurement of area. The limit of area within which individual parcels are not shown. To convert hectares to acres multiply by 2.471 05. To convert acres to hectares multiply by 0.404 69.

NATIONAL GRID REFERENCE

The grid lines form part of the National Grid and are at 100 metre intervals. To give a unique reference defining the position of a point to within 10 metres proceed as follows:

- Take the two letters preceding the sheet number. EXAMPLE from sheet: TQ 0529
- Take the west edge of the grid square in which the point lies and read the figure opposite this line on the north or south margin. 058
- Take the east edge of the grid square in which the point lies and read the figure opposite this line on the east or west margin. 291
- Take the north edge of the grid square in which the point lies and read the figure opposite this line on the north or south margin. 058

The resulting four figure number is the National Grid Reference. For further information see 'An Introduction to the Projection for Ordnance Survey Maps and the National Reference System'.

