



© Crown copyright 1980

COMPILATION DATA
Levelled 1939
Boundaries Feb 1979

Scale 1:2500
(a) Surveyed
(b) Reconstituted from former County Series plans and revised
(c) Revised

Surveys of changes since the publication of this plan may be available. Enquiries should be addressed to the Director General or to the local Ordnance Survey office.
HEIGHTS are given in METRES above the Newlyn Datum.
Bench mark lists, which may contain later levelling information and particulars of bench marks to which no values have been shown, are obtainable from the Director General, Ordnance Survey.
The representation on this plan of a road, track or path is no evidence of the existence of a right of way.
The alignment of tunnels where shown is approximate.
Details of symbols and abbreviations used can be obtained from Ordnance Survey, Southampton.



Table of symbols for boundaries and features: ENGLAND & WALES, SCOTLAND, Boundaries (County, District, etc.), Boundary markings (Base of Bank, Centre of Road, etc.), and Features (Face of Fence, Top of Bank, etc.).

Made and published by the Director General of the Ordnance Survey, Southampton.
AREAS
Area measurement is to plan edge only.
The number and area, in hectares (ha) and acres, is shown within each parcel of land.
EXAMPLE: 4267 parcel number, 3.96 ha area in hectares, 9.79 acres area in acres.
When identifying a parcel it is important to specify the number of the plan on which it falls.
Enclosures or features joined for measurement of area.
Limit of area within which individual parcels are not shown.
To convert hectares to acres multiply by 2.471 05.
To convert acres to hectares multiply by 0.404 69.
NATIONAL GRID REFERENCE
The grid lines form part of the National Grid and are at 100 metre intervals. To give a unique reference defining the position of a point to within 10 metres proceed as follows:
EXAMPLE from sheet TQ 0529
1. Take the two letters preceding the sheet number TQ
2. Take the west edge of the grid square in which the point lies and read the figures opposite this line on the north or south margin. Estimate tens of metres from the grid line to the point (distance e) 058
3. Take the south edge of the grid square in which the point lies and read the figures opposite this line on the east or west margin. Estimate tens of metres from the grid line to the point (distance n) 291
4. The resulting four figure number is the Northing 0588 2916
The full ten metre reference is given by writing first the letters TQ 05882916 followed by the Easting and then by the Northing TQ 05882916 058
For further information see 'An Introduction to the Projection for Ordnance Survey Maps and the National Reference System'

