




Made and published by the Director General of the Ordnance Survey, Southampton.

Made and published by the Director General of the Ordnance Survey, Southampton.

COMPILATION DATA

Levelled.....1952
Boundaries.....May 1975

(a) 1:2500 scale (b) 1:1250 scale (photographically reduced)
Surveys of changes since the publication of this plan may be available. Enquiries should be addressed to the Director General or to the local Ordnance Survey office.
Bench mark lists, which may contain later levelling information and particulars of bench marks to which no values have been shown, are obtainable from the Director General, Ordnance Survey. The representation on this plan of roads, tracks or paths is evidence of the existence of a right of way. The alignment of tunnels where shown is approximate.



ABBREVIATIONS

B.H.	Bear House	L.B.Stn.	Lifboat Station	R.H.	Road House
B.M.	Bench Mark	L.C.	Level Crossing	rp.	Revision Point
B.P.	Boundary Post	L.G.	Loading Gauge	S.	Slope
B.S.	Boundary Stone	L.H.	Lighthouse	S.B.	Signal Box
C.	Crane	L.T.	Lighting Tower	S.D.	Signal Bridge
C.H.	Club House	m.	Metre	S.L.	Signal Light
Chy.	Chimney	M.H.W.	Mean High Water	SI	Sluice
Ca.	Cape	M.L.W.	Mean Low Water	Sr.	Spring
Cd.	Captain	M.H.W.S.	Mean High Water Springs	S.S.	Signal Station
D.F.	Drinking Fountain	M.L.W.S.	Mean Low Water Springs	T.C.P.	Telephone Call Post
E.P.	Electricity Pillar or Pole	N.T.L.	Normal Tidal Limits	Tk.	Track or Trough
E.T.L.	Electricity Transmission Line	P.	Pillar, Pole or Post	Tr.	Traverse Station
F.A.	Fire Alarm	P.C.	Public Convenience	W.	Well
F.A.P.	Fire Alarm Pillar	P.C.B.	Police Call Box	W.B.	Weighbridge
F.B.	Fitter Bed or Foot Bridge	P.H.	Public House	Wd.P.	Wind Pump
F.B.M.	Fundamental Bench Mark	P.O.	Post Office	W.S.	Works
F.S.	Flagstaff	P.P.	Pump	W.P.	Water Point
F.Stn.	Fire Station	P.T.P.	Police Telephone Pillar	W.T.	Water Tap
G.P.	Guide Post				
G.V.C.	Gas Valve Compound				
H.	Hedest or Hydronic				
H.	Hectares				
L.B.	Letter Box				

SYMBOLS

	Non-coniferous tree		Site of antiquity
	Coniferous tree		Culvert
	Surveyed tree		Direction of water flow
	Orchard area		Pylon
	Coppice area		Electricity Transmission Line
	Scrub		Triangulation station
	Sloping masonry		Traverse station (permanent)
	Roofed building		Bench mark
	Heath		Surface level
	Bracken & rough grassland		Revision point
	Glasshouse		Revision point & bench mark coincident
	Archway		
	Marsh		
	Change of boundary notes		
	Reeds		

ENGLAND & WALES

B.B.	Base of Bank	C.B.	Centre of Bank	C.S.	Centre of Stream, etc.	Daf.	Distanced	E.K.	Edge of Kerb	S.R.	Side of Road, etc.
C.B.	Centre of Bank	C.S.	Centre of Stream, etc.	Daf.	Distanced	E.K.	Edge of Kerb	S.R.	Side of Road, etc.		
C.C.S.	Centre of Covered Stream										
C.D.	Centre of Drain, etc.										

SCOTLAND

	Region or Islands Area		
	District		
	Local Authority		
	Community (Wales)		
	Electoral Division		
	Ward		
	Consistency (Co or Burgh)		

BOUNDARIES

	Parish Boundary		Borough Boundary
	County Boundary		Civil Parish Boundary
	Community (Wales) Boundary		Electoral Division Boundary
	Ward Boundary		Constituency (Co or Burgh) Boundary

COINCIDENT BOUNDARIES ARE SHOWN BY THE FIRST APPROPRIATE SYMBOL ABOVE, E.G. - B.C. CONST. & E.D. Bdy.

NATIONAL GRID REFERENCE

The grid lines form part of the National Grid and are at 100 metre intervals. To give a unique reference defining the position of a point to within 10 metres proceed as follows -

EXAMPLE: 4267 9694

4267 = parcel number
9694 = area in acres

To convert hectares to acres multiply by 2.471 05
To convert acres to hectares multiply by 0.404 69

1. Take the two letters preceding the sheet number - TQ 059
2. Take the west edge of the grid square in which the point lies and read the figures opposite this line on the north or south margin - 058
3. Take the south edge of the grid square in which the point lies and read the figures opposite this line on the east or west margin - 291
4. The full ten metre reference is given by writing first the letters, followed by the Easting and then by the Northing - TQ 0582914

AREAS

Area measurement is to plan edge only.
Estimate area in hectares (ha) and acres, as shown within each parcel of land.

EXAMPLE: 4267 9694 = parcel number
9694 = area in acres

When identifying a parcel it is important to specify the number of the plan on which it falls. Boundaries or features joined for measurement of area are not shown.

Limits of area within which individual parcels are not shown.

To convert hectares to acres multiply by 2.471 05
To convert acres to hectares multiply by 0.404 69

NATIONAL GRID REFERENCE

The grid lines form part of the National Grid and are at 100 metre intervals. To give a unique reference defining the position of a point to within 10 metres proceed as follows -

EXAMPLE: 4267 9694

4267 = parcel number
9694 = area in acres

To convert hectares to acres multiply by 2.471 05
To convert acres to hectares multiply by 0.404 69

1. Take the two letters preceding the sheet number - TQ 059
2. Take the west edge of the grid square in which the point lies and read the figures opposite this line on the north or south margin - 058
3. Take the south edge of the grid square in which the point lies and read the figures opposite this line on the east or west margin - 291
4. The full ten metre reference is given by writing first the letters, followed by the Easting and then by the Northing - TQ 0582914

For further information see 'An Introduction to the Projection for Ordnance Survey Maps and the National Reference System'.