




Made and published by the Director General of the Ordnance Survey, Southampton.



**COMPILED DATA**  
 Levelled 1957,58  
 Boundaries Jun 1975  
 (b) May 1975

1:2500 scale  
 (a) Surveyed  
 (b) Reconstructed from former County Series plans and revised  
 (c) Revised

Surveys of changes since the publication of this plan may be available. Enquiries should be addressed to the Director General or to the local Ordnance Survey office.

Bench mark lists, which may contain later levelling information and particulars of bench marks to which no values have been shown, are obtainable from the Director General, Ordnance Survey.

HEIGHTS are given in METRES above the Newlyn Datum.

The representation on this plan of a road, track or path is no evidence of the existence of a right of way.

The alignment of tunnels where shown is approximate.

© Crown copyright 1975

**ABBREVIATIONS**

B.H.	Beer House	L.C.	Level Crossing	R.H.	Road House
B.M.	Bench Mark	L.G.	Loading Gauge	R.P.	Revision Point
B.S.	Boundary Stone	L.H.	Lighthouse	S.	Stone
C.	Crane	L.T.	Lighting Tower	S.B.	Signal Bridge
Ch.	Club House	M.	Miscellaneous	S.D.	Sundial
Chm.	Chimney	M.H.W.	Mean High Water	S.L.	Signal Light
Cn.	Canopy	M.H.W.S.	Mean High Water Springs	S.P.	Signal Post
D.F.	Drinking Fountain	M.L.W.	Mean Low Water	Spr.	Spring
E.P.	Electricity Pillar or Pole	M.L.W.S.	Mean Low Water Springs	S.S.	Signal Station
E.T.L.	Electricity Transmission Line	M.P.	Mile or Mooring Post	S.St.	Signal Station
F.A.	Fire Alarm	M.P.U.	Mail Pick-up	T.C.B.	Telephone Call Box
F.A.P.	Fire Alarm Pillar	M.S.	Mile Stone	T.C.P.	Telephone Call Post
F.B.	Filter Bed or Foot Bridge	N.T.L.	Normal Tidal Limit	Tk.	Tank or Track
F.F.	Flagstaff	P.	Pillar, Pole or Post	Tr.	Traverse Station
F.H.	Fire Hydrant	P.L.	Public Limit	Tr.	Traverse Station
F.S.	Flagstaff	P.C.	Public Convenience	W.	Well
G.P.	Gas Valve Compound	P.H.	Police Call Box	W.B.	Wrightbridge
H.	Hydrant or Hydraulic	P.H.	Public House	W.P.	Wind Pump
Hc.	Hectares	P.O.	Post Office	Wk.	Works
L.B.	Letter Box	P.P.	Police Telephone Pillar	W.P.	Water Pump
		P.T.P.	Police Telephone Pillar	W.T.	Water Tap

**SYMBOLS**

Non-coniferous trees	Slopes	Site of antiquity
Coniferous trees	Cliff	Calvert
Surveyed trees	Cave entrance	Direction of water flow
Orchard trees	Rock	Prison
Boulders	Electricity Transmission Line	Electricity Transmission Line
Sloping masonry	Triangulation station	Triangulation station
Roof led building	Traverse station (permanent)	Traverse station (permanent)
Glasshouse	Bench mark	Bench mark
Archway	Surface level	Surface level
Change of boundary meeting	Revision point	Revision point
see AREAS notes	Revision point & bench mark coincident	Revision point & bench mark coincident

**BOUNDARIES**

ENGLAND & WALES	SCOTLAND
County	Region or Islands Area
District	District
London Borough	District
Civil Parish (England)	District
Community (Wales)	District
Electoral Division	District
Ward	District
Constituency (Co or Baro)	District
County Boundary	Region or Islands Area
District Boundary	District
London Borough Boundary	District
Civil Parish Boundary	District
Community Boundary	District
Electoral Division Boundary	District
Ward Boundary	District
Constituency Boundary	District

**AREAS**  
 Area measurement is to point edge only.  
 The number and area in hectares (ha) and acres (a) shown within each parcel of land.

EXAMPLE: 4267 parcel number  
 1.807ha area in hectares  
 4.47 area in acres

When identifying a parcel it is important to specify the number of the plan on which it falls. Enclosures or features joined for measurement of area are not shown.

Limit of area within which individual parcels are not shown: 0.0588 ha (0.142 a)

To convert hectares to acres multiply by 2.471 05  
 To convert acres to hectares multiply by 0.404 69

**NATIONAL GRID REFERENCE**  
 The grid lines form part of the National Grid and are at 100 metre intervals. To give a unique reference defining the position of a point or within 10 metres proceed as follows:

1. Take the two letters preceding the sheet number. (e.g. TQ)
2. Take the west edge of the grid square in which the point lies and read the figure opposite the line on the north or south margin. Estimate tenths of metres from the grid line to the point (distance a).
3. Take the south edge of the grid square in which the point lies and read the figure opposite the line on the east or west margin. Estimate tenths of metres from the grid line to the point (distance b).
4. The full ten metre reference is given by writing first the letters followed by the Easting number and then by the Northing number. (e.g. TQ 958294)

For further information see: An Introduction to the Projection for Ordnance Survey Maps and the National Reference System.