



Made and published by the Director General of the Ordnance Survey, Southampton.

Made and published by the Director General of the Ordnance Survey, Southampton.


COMPILED DATA

Levelled.....1952
Boundaries.....Jan 1979

(1) Surveyed
(2) Reconstituted from former County Series plans and revised.
(3) Revised.

Surveys of changes since the publication of this plan may be available. Enquiries should be addressed to the Director General or to the local Ordnance Survey office.

HEIGHTS are given in METRES above the Newlyn Datum.
Bench mark lists, which may contain level information and particulars of bench marks of which no values have been shown, are obtainable from the Director General, Ordnance Survey.
Representation on this plan of a road, track or path is evidence of the existence of a right of way.
The alignment of tunnels where shown is approximate.



ABBREVIATIONS

B.H.	Bench Mark	L.S.	Level Station	R.H.	Road House
B.M.	Bench Mark	L.C.	Level Crossing	R.S.	Revision Stone
B.P.	Boundary Pillar	L.G.	Loading Gauge	S.	Stone
B.S.	Boundary Stone	L.H.	Lighthouse	S.B.	Signal Box
C.	Crate	L.T.	Lighting Tower	S.L.	Signal Light
Ch.	Chimney	M.H.W.	Mean High Water	S.P.	Signal Post
Ch.H.	Club House	M.H.W.S.	Mean High Water Springs	S.S.	Signal Staff
Ci.	Casson	M.L.W.	Mean Low Water	S.Si.	Signal Stone
C.P.	Drinking Fountain	M.L.W.S.	Mean Low Water Springs	S.Si.	Signal Stone
E.P.	Electricity Pole or Post	M.P.	Mile or Mooring Post	S.Si.	Signal Stone
E.T.L.	Electricity Transmission Line	M.P.L.	Mile or Mooring Post	S.Si.	Signal Stone
F.A.	Fire Alarm	N.P.L.	Normal Tidal Limit	T.C.B.	Telephone Call Box
F.A.P.	Fire Alarm Pillar	N.S.	Mile Stone	T.C.P.	Telephone Call Post
F.B.	Filter Bed or Foss Bridge	N.T.L.	Normal Tidal Limit	T.K.	Tank or Trunk
F.P.	Flagstaff	N.P.L.	Normal Tidal Limit	T.L.	Trough
F.S.	Fire Station	P.C.	Public Call Box	T.S.	Traverse Station
F.P.	Flagstaff	P.C.B.	Public Call Box	W.	Well
F.S.	Fire Station	P.C.P.	Public Call Post	W.B.	Weightbridge
F.A.	Fire Alarm	P.D.	Public House	W.P.	Wind Pump
F.P.	Flagstaff	P.O.	Post Office	W.P.	Wind Pump
F.S.	Fire Station	P.P.	Police Post	W.P.	Wind Pump
F.A.	Fire Alarm	P.T.P.	Police Telephone Pillar	W.T.	Water Tap

SYMBOLS

Non-coniferous trees	Slopes	Site of antiquity
Coniferous trees	Cliff	Culvert
Surveyed trees	Cave entrance	Direction of water flow
Orchard trees	Rock	Pylon
Coppice, over	Boulders	E.T.L. Electricity Transmission Line
Scrub	Sloping masonry	Transpiration station
Heath	Roofed building	Traverse station (permanent)
Bracken, rough grassland	Glasshouse	Bench mark
Saltings	Archway	Surface level
Reeds	Change of boundary meaning	Revision point
	see AREAS notes	Revision point & bench mark coincident

BOUNDARIES

England & Wales	County	Scotland	Region or Islands Area
County	District	District	District
London Borough	Civil Parish (England)	Not shown	Not shown
Community (Wales)	Electoral Division	Electoral Division	Electoral Division
Ward	Constituency (Co or Boro)	Ward	Constituency (Co or Boro)
		Baro Const. Bdy	Baro Const. Bdy
		Ward Bdy	Ward Bdy
		Borough Const. Bdy	Borough Const. Bdy
		Co Const. Bdy	Co Const. Bdy

BOUNDARY MEASUREMENTS

B.B.	Base of Bank	C.R.	Centre of Road	F.F.	Face of Fence	T.B.	Top of Bank
C.B.	Centre of Bank	C.S.	Centre of Stream	F.W.	Face of Wall	T.H.	Track of Hedge
C.C.S.	Centre of Covered Stream	Def.	Defence	R.H.	Roof of Hedge	T.S.	Track of Stream
C.D.	Centre of Drain, etc.	E.K.	Edge of Kiosk	S.R.	Side of River, etc.	U.S.	Underside

AREAS

Area measurement is to plan edges only.
The number and area, in hectares (ha) and acres, is shown within each parcel of land.

EXAMPLE: 1.057ha area in hectares
4.47 area in acres

When identifying a parcel it is important to specify the number of the plan on which it falls.
Limits of areas within which individual parcels are not shown.

To convert hectares to acres multiply by 2.471 05
To convert acres to hectares multiply by 0.404 69

NATIONAL GRID REFERENCE

The grid lines form part of the National Grid and are at 100 metre intervals. To give a unique reference defining the position of a point to within 10 metres proceed as follows—

EXAMPLE from sheet TQ 0589

- Take the two letters preceding the sheet number. TQ
- Take the west edge of the grid square in which the point lies and read the figure opposite this line on the north or south margin. 292
- Estimate tenths of metres from the grid line to the point (distance $\times 10$). 058
- Take the south edge of the grid square in which the point lies and read the figure opposite this line on the east or west margin. 291
- The resulting four figure number is the Easting. 2916
- The full ten metre reference is given by writing first the Easting, followed by the Easting and then by the Northing. TQ 05892916

For further information see 'An Introduction to the Projection for Ordnance Survey Maps and the National Reference System.'