

Made and published by the Director General of the Ordnance Survey, Southampton.

Made and published by the Director General of the Ordnance Survey, Southampton.

**COMPILATION DATA**


Levelled.....1952  
 Boundaries.....May 1979

† 1:2500 scale \* 1:1250 scale (photographically reduced)

(a) Surveyed.  
 (b) Reconstructed from former County Survey plans and revised.  
 (c) Revised.

Surveys of changes since the publication of this plan may be available. Enquiries should be addressed to the Director General or to the local Ordnance Survey office.

HEIGHTS are given in METRES above the Newlyn Datum.  
 Bench mark lists, which may contain later levelling information and particulars of bench marks to which no values have been shown, are obtainable from the Director General, Ordnance Survey.  
 The representation on this plan of roads, tracks or paths is no evidence of the existence of a right of way.  
 The alignment of tunnels where shown is approximate.



ABBREVIATIONS		SYMBOLS		BOUNDARIES	
B.H.	Beer House	—	Slopes	—	England & Wales
B.M.	Bench Mark	—	Cliff	—	County
B.P.	Boundary Post	—	Cave entrance	—	District
B.S.	Boundary Stone	—	Direction of water flow	—	London Borough
C.M.	Crane	—	Rock	—	City/Parish (England)
C.H.	Club House	—	Boulders	—	Community (Wales)
Cy.	Chimney	—	Sloping masonry	—	Electoral Division
Ch.	Chapman	—	Roofted building	—	Ward
D.F.	Drinking Fountain	—	Archway	—	Constituency (County, Borough or European Assembly)
E.P.	Electricity Pole or Post	—	Change of boundary marking	—	Baro Const. Bdy
E.T.L.	Electricity Transmission Line	—	Revision point & bench mark coincident	—	Borough Const. Bdy
F.A.	Fire Alarm	—		—	Coast Bdy
F.B.	Filter Bed or Foot Bridge	—		—	
F.B.M.	Fundamental Bench Mark	—		—	
F.P.	Flagstaff	—		—	
F.S.	Fire Station	—		—	
G.P.	Guide Post	—		—	
G.V.C.	Gas Valve Compound	—		—	
H.	Hydrant or Hydraulic	—		—	
Hs.	Hastings	—		—	
L.B.	Letter Box	—		—	
L.C.	Level Crossing	—		—	
L.G.	Loading Gauge	—		—	
L.H.	Lighthouse	—		—	
L.M.	Lighting Mast	—		—	
L.P.	Lighting Post	—		—	
M.H.W.	Mean High Water	—		—	
M.H.W.S.	Mean High Water Springs	—		—	
M.L.W.	Mean Low Water	—		—	
M.L.W.S.	Mean Low Water Springs	—		—	
M.P.	Mail or Hooping Post	—		—	
M.P.P.	Mail Pick-up	—		—	
M.S.	Mile Stone	—		—	
N.L.	Normal Tidal Limits	—		—	
N.P.	Pillar, Pole or Post	—		—	
N.P.S.	Normal Path	—		—	
N.P.C.	Public Convenience	—		—	
N.P.O.	Police Call Box	—		—	
N.P.P.	Public House	—		—	
N.P.O.	Post Office	—		—	
N.P.P.	Pump	—		—	
N.P.P.	Police Telephone Pillar	—		—	
R.H.	Road House	—		—	
R.P.	Revision Point	—		—	
S.	Stone	—		—	
S.B.	Signal Base	—		—	
S.Br.	Signal Bridge	—		—	
S.D.	Sundial	—		—	
S.L.	Signal Light	—		—	
S.Li.	Sluice	—		—	
S.P.	Signal Post	—		—	
S.P.	Signal Station	—		—	
T.C.B.	Telephone Call Box	—		—	
T.C.P.	Telephone Call Post	—		—	
T.C.	Tank or Trunk	—		—	
T.P.	Trough	—		—	
T.S.	Traverse station (permanent)	—		—	
T.S.	Traverse station (temporary)	—		—	
W.	Wall	—		—	
W.B.	Wagbridge	—		—	
W.P.	Wind Pump	—		—	
W.P.	Works	—		—	
W.P.	Water Point	—		—	
W.T.	Water Tap	—		—	

**AREAS**

Area measurements in this plan are in hectares (ha) and acres. Area measurements in this plan are in hectares (ha) and acres. The number and area, in hectares (ha) and acres, is shown within each parcel of land.

EXAMPLE: 1 809ha 4.47 acres in hectares  
 4257 parcel number  
 1 809ha 4.47 acres in acres

When identifying a parcel it is important to specify the number of the plan on which it falls. Enclosures or features joined for measurement of area are not shown. Limit of area within which individual parcels are not shown.

To convert hectares to acres multiply by 2.471 05  
 To convert acres to hectares multiply by 0.404 69

**NATIONAL GRID REFERENCE**

The grid lines form part of the National Grid and are at 100 metre intervals. To give a unique reference defining the position of a point to within 10 metres proceed as follows—

EXAMPLE from sheet TQ 0529

- Take the two letters preceding the sheet number. TQ 0529
- Take the west edge of the grid square in which the point lies and read the figure opposite this line on the north or south margin. 058
- Take the south edge of the grid square in which the point lies and read the figure opposite this line on the east or west margin. 291
- Estimate tenths of metres from the grid line to the point (distance 43). The resulting four figure number is the Northing. 058291
- The full six figure reference is given by writing first the letters followed by the Easting and then by the Northing. TQ 05829143

For further information see 'An Introduction to the Projection for Ordnance Survey Maps and the National Reference System.'