



**COMPILATION DATA**

Levelled ..... 1957  
 Boundaries ..... Mar 1979

1:1250 scale (photographically reduced)  
 (a) Surveyed  
 (b) Reconstructed from former County Series plans and revised.  
 (c) Revised.

Surveys of changes since the publication of this plan may be available. Enquiries should be addressed to the Director General or to the local Ordnance Survey office.

HEIGHTS are given in METRES above the Newlyn Datum.  
 Bench mark lists, which may contain later levelling information and particulars of bench marks to which no values have been shown, are obtainable from the Director General, Ordnance Survey.  
 The representation on this plan of a road, track or path is no evidence of the existence of a right of way.  
 The alignment of tunnels where shown is approximate.

**ABBREVIATIONS**

B.H.	Beer House	L.B.Sta.	Lifeboat Station	R.H.	Road House
B.M.	Bench Mark	L.C.	Level Crossing	rp.	Revision Point
B.P.	Boundary Post	L.G.	Loading Gauge	S.	Stone
B.S.	Boundary Stone	L.H.	Lighthouse	S.B.	Signal Box
C.	Crane	L.T.	Lighting Tower	S.Br.	Signal Bridge
C.H.	Club House	M.	Mean High Water	S.D.	Signal Post
Cm.	Cemeter	M.H.W.	Mean High Water Springs	S.L.	Signal Light
Co.	Copart	M.L.W.	Mean Low Water	Sl.	Sluice
D.F.	Drinking Fountain	M.L.W.S.	Mean Low Water Springs	S.P.	Spring
D.P.	Drinking Post	M.L.W.S.	Mean Low Water Springs	Spr.	Spring
E.P.	Electricity Pillar or Pole	M.P.	Mile or Flooring Post	S.Sa.	Signal Station
E.T.L.	Electricity Transmission Line	M.P.U.	Mail Pickup	Sr.	Stream
F.A.	Fire Alarm	N.T.	Normal Tidal Limit	T.C.B.	Telephone Call Box
F.A.P.	Fire Alarm Pillar	P.	Pillar, Pole or Post	T.C.P.	Telephone Call Post
F.B.	Filter Bed or Post Bridge	P.C.	Public Convenience	Tk.	Tank or Track
F.F.M.	Fundamental Bench Mark	P.H.	Public House	Tr.	Trough
F.S.	Flagstaff	P.C.	Public Convenience	Tr.	Traverse Station
F.St.	Fire Station	P.C.	Public Convenience	Tr.	Traverse Station
G.P.	Grave Post	P.C.	Public Convenience	Tr.	Traverse Station
G.V.C.	Gas Valve Compound	P.C.	Public Convenience	Tr.	Traverse Station
H.	Hydrant or Hydraulic	P.C.	Public Convenience	Tr.	Traverse Station
H.	Hazard	P.C.	Public Convenience	Tr.	Traverse Station
H.	Hydrant or Hydraulic	P.C.	Public Convenience	Tr.	Traverse Station
H.	Hazard	P.C.	Public Convenience	Tr.	Traverse Station
L.B.	Letter Box	P.C.	Public Convenience	Tr.	Traverse Station
L.B.	Letter Box	P.C.	Public Convenience	Tr.	Traverse Station

**SYMBOLS**

	Non-coniferous trees		Slopes
	Coniferous trees		Cliff
	Surveyed trees		Cave entrance
	Orchard trees		Direction of water flow
	Coppice scrub		Pylon
	Scrub		Electricity Transmission Line
	Bracken rough ground		Triangulation station
	Marsh		Traverse station (permanent)
	Change of boundary merging		Bench mark
	SEE AREAS notes		Surface level
			Revision point
			Revision point and bench mark coincident

**BOUNDARIES**

	ENGLAND & WALES		SCOTLAND
	County		Region or Islands Area
	District		District
	Civil Parish (England)		Not shown
	Community (Wales)		Electoral Division
	Ward		Constituency (Co or Burgh)
	Constituency (Co or Burgh)		Borough Const. Bdy
	Borough Const. Bdy		Burgh Const. Bdy
	Burgh Const. Bdy		Co Const. Bdy

Concurrent boundaries are shown by the first appropriate symbol above, e.g. County & E.D. Bdy.

For Ordnance Survey purposes County Boundary is deemed to be the limit of the parish structure whether or not a parish area adjoins.

**AREAS**

Area measurement is to plan edge only.  
 The number and area, in hectares (ha) and acres, is shown within each parcel of land.

EXAMPLE: 4267 ..... parcel number  
 4.47 ..... area in hectares  
 11.058 ..... area in acres

When identifying a parcel it is important to specify the number of the plan on which it falls.  
 Enclosures or features joined for measurement of area .....  
 Limits of area within which individual parcels are not shown .....  
 To convert hectares to acres multiply by 2.471 058  
 To convert acres to hectares multiply by 0.404 69

**NATIONAL GRID REFERENCE**

The grid lines form part of the National Grid and are at 100 metre intervals. To give a unique reference defining the position of a point to within 10 metres proceed as follows:

EXAMPLE from sheet TQ 0529

- Take the two letters preceding the sheet number: TQ
- Read the west edge of the grid square in which the point lies and read the figures opposite this line on the north or south margin: 058
- Estimate tenths of metres from the grid line to the point (distance 40) and read the figures opposite this line on the east or west margin: 291
- Estimate tenths of metres from the grid line to the point (distance 4) and read the figures opposite this line on the east or west margin: 291

The resulting four figure number is the Northing: 291 4

The full ten metre reference is given by writing first the letters, followed by the Easting and then by the Northing: TQ 0582914

For further information see "An Introduction to the Projection for Ordnance Survey Maps and the National Reference System".