



Made and published by the Director General of the Ordnance Survey, Southampton.

Made and published by the Director General of the Ordnance Survey, Southampton.

**COMPILED DATA**

Levelled.....1952.57  
Boundaries.....Dec 1978

(A) Apr 1978

**HEIGHTS** are given in METRES above the Newlyn Datum.  
Bench mark lists, which may contain later levelling information and particulars of bench marks to which no values have been shown, are obtainable from the Director General, Ordnance Survey.  
The representation on this plan of a road, track or path is no evidence of the existence of a right of way.  
The alignment of contours where shown is approximate.

Copyright 1979  
**AN ST 9426-9526**

**ABBREVIATIONS**

B.H.	Bench House	R.H.	Road House
B.M.	Bench Mark	rp	Revision Point
B.P.	Boundary Post	S	Level Crossing
B.S.	Boundary Stone	S.C.	Leveling Staff
C	Crane	S.L.	Signal Light
Ch	Club House	S.S.	Signal Mast
Chy	Chimney	S.P.	Signal Post
Cn	Capstan	SP	Spring
D.F.	Drinking Fountain	S.S.P.	Signal Station
E.P.	Electricity Pylon or Pole	T.C.P.	Telephone Call Post
E.T.L.	Electricity Transmission Line	T.C.P.	Telephone Call Post
F.A.	Fire Alarm	T.C.P.	Telephone Call Post
F.A.P.	Fire Alarm Pylon	T.C.P.	Telephone Call Post
F.B.M.	Filter Bed or Foot Bridge	T.C.P.	Telephone Call Post
F.S.	Fundamental Bench Mark	T.C.P.	Telephone Call Post
F.S.M.	Fire Station	T.C.P.	Telephone Call Post
G.P.	Guide Post	T.C.P.	Telephone Call Post
G.V.C.	Gas Valve Compensator	T.C.P.	Telephone Call Post
H.	Hydrant or Hydraulic	T.C.P.	Telephone Call Post
H.C.	Hydrant	T.C.P.	Telephone Call Post
L.B.	Letter Box	T.C.P.	Telephone Call Post

**SYMBOLS**

Non-coniferous trees	Coniferous trees	Surveyed trees	Orchard trees	Coppice scrub	Marsh	Saltings	Reeds			
Slopes	Cave entrance	Rock	Sloping masonry	Roofed building	Glasshouse	Archway	Change of boundary marking	SEE AREAS NOTES		
Site of antiquity	Culvert	Direction of water flow	Pylon	Electricity Transmission Line	Transpiration station	Transverse station (permanent)	Bench mark	Surface level	Revision point	Revision point & bench mark coincident

**BOUNDARIES**

ENGLAND & WALES	County	London Borough	Civil Parish (England)	Community (Wales)	Electoral Division	Ward	Consistency (Co or Boro)
SCOTLAND	Region or Islands Area	District	Not shown	Not shown	Electoral Division	Ward	Consistency (Co or Boro)

Concurrent boundaries are shown by the first appropriate symbol above, e.g. Boro Const & E D Bdy.

For Ordnance Survey purposes County Boundary is defined to be the limit of the parish structure whether or not a parish area adjoins.

**BOUNDARY MEASUREMENTS**

B.B.	Base of Bank	C.R.	Centre of Road, etc.	F.F.	Face of Fence	T.B.	Top of Bank
C.B.	Centre of Bank	C.S.	Centre of Stream, etc.	F.W.	Face of Wall	T.H.	Track of Hedge
C.C.S.	Centre of Covered Stream	Def.	Defence	R.W.	Roof of Ridge	T.S.	Track of Stream
C.D.	Centre of Drain, etc.	E.K.	Edge of Kerb	S.R.	Side of River, etc.	Und.	Underside

**AREAS**  
Area measurement is to plan edge only.  
Enclosures or features joined for measurement of area, are shown within each parcel of land.  
The number and area, in hectares (ha) and acres, is shown within each parcel of land.  
EXAMPLE: 1 807ha 4.47 acres

When identifying a parcel it is important to specify the number of the plan on which it falls.  
Enclosures or features joined for measurement of area, are shown within each parcel of land.  
Limits of area within which individual parcels are not shown.  
To convert hectares to acres multiply by 2.471 05.  
To convert acres to hectares multiply by 0.404 69.

**NATIONAL GRID REFERENCE**  
The grid lines form part of the National Grid and are at 100 metre intervals. To give a unique reference defining the position of a point to within 10 metres proceed as follows -  
EXAMPLE: From sheet TQ 0929

- Take the two letters preceding the sheet number. TQ 0929
- Take the west edge of the grid square to which the point lies and read the figure opposite this line on the north or south margin. 058
- Estimate tenths of metres from the grid line to the point (distance in metres). 29
- The resulting four figure number is the Northing. 058 29
- Take the south edge of the grid square to which the point lies and read the figure opposite this line on the east or west margin. 391
- Estimate tenths of metres from the grid line to the point (distance in metres). 058
- The resulting four figure number is the Easting. 391 058
- The full ten metre reference is given by writing first the letters, followed by the Easting and then by the Northing. TQ 0929 391 058

For further information see 'An Introduction to the Projection for Ordnance Survey Maps and the National Reference System.'